



HE1000 WiFi

 Enhanced Magnet	 Stealth Magnets Design	 Headband Gen.2	 Nanometer Thickness Diaphragm
 WiFi Streaming		 HYMALAYA <i>Mini</i>	

Hello

Congratulations on your purchase of the HIFIMAN HE1000 WiFi open-back planar magnetic headphone. HIFIMAN is dedicated to the development and manufacture of industry-leading high-fidelity personal audio products, including audiophile-grade headphones, amplifiers, digital audio players, and more.

Your new HE1000 WiFi represents our philosophy of popularizing high-definition wireless audio by connecting the headphone to your favorite streaming platforms via a WiFi network. Of course, Bluetooth 5.1 and USB-C are options as well, making the HE1000 WiFi a true one-model-fits-all personal HiFi audio solution.

Of course, as a HIFIMAN headphone, the HE1000 WiFi also includes a host of the company's technological innovations, including our ultra-efficient Himalaya Mini R-2R DAC (digital-to-analog converter), a nanometer thickness diaphragm, stealth magnets that feature a mix of enhanced rare-earth-free and neodymium materials, and a newly designed composite headband designed for maximum comfort over extended listening sessions.

In the following pages, you will learn the few simple steps required to connect the headphone to your WiFi network, and best practices including proper care and maintenance that will help the HE1000 WiFi provide years of enjoyment.




Stealth Magnets



Stealth Magnets are created using high-precision laser technology for improved sound with ultra-low distortion.

The Stealth Magnet's structure optimizes the air flow and reflection in the magnetic gap of the coil, resulting in sound reproduction that is pure and natural.





Nanometer Thickness Diaphragm



Assures Remarkable Reproduction


Unlike conventional dynamic drivers, HIFIMAN's planar magnetic headphones utilize a super-thin film in proximity to the magnet to produce sound that is detailed, with a wide soundstage. (The thinner the film, the lower the mass, which yields a quick response with low distortion.)

The film used in the HE1000 WiFi is so thin that it is a nanometer thick - a HIFIMAN innovation. If viewed from the side, it would be invisible to the naked eye. This development is a cornerstone of the company's reputation for remarkable sound.




Enhanced Magnet

HIFIMAN uses rare-earth-free magnetic materials to achieve the exceptional sensitivity of a planar speaker, through structural and material optimization.



Normal magnets



Enhanced magnets



Composite Headband

The new HIFIMAN composite headband is constructed of steel, plastic, and microfiber for pure comfort for hours of listening pleasure.





The WiFi streaming technology supports high-speed transmission in high-bitrate, and multi-format lossless music.



Support for most online streaming services



Indoors, outdoors, wireless, wired... They cover a wide range of scenarios.



WiFi streaming mode

Play music from online store





Support high resolution Bluetooth profiles



USB audio mode

A True All-in-One System !



Function Description of HE1000 WiFi Headband Headphones

The HE1000 WiFi is an all-in-one over-ear headphone that supports high-definition Bluetooth playback, media playback, and USB Audio. It defaults to Bluetooth mode when turned on, and you can cycle through the three modes by pressing the function button.

HE1000 WiFi Features Buttons and Functions

1. Power On/Off Button: Press 3-5 seconds to power the device. It will default to Bluetooth mode.
2. Function Button: Press the button to select a preferred connection: WiFi, Bluetooth, or USB-C
3. Volume Buttons: Tap “+” to increase the volume; “-” to decrease the volume
4. WiFi Reset Jack: To reset the WiFi network, insert a paper clip or small pin into the reset jack for 3-5 seconds. The WiFi function indicator light will flash blue and red three times, indicating the WiFi connection is cleared.

Bluetooth LED Light Display

In Bluetooth mode, the function key’s LED light is off. When ready to pair, the Power Button light alternately blinks blue and green.

During playback, the LED light blinks blue at five second intervals. When paused, the LED light blinks green at five second intervals

WiFi Mode

In WiFi mode, the LED remains green. (It may take up to two minutes to enter WiFi mode after the headphone is turned on.)

The headphone will enter AP (access point) mode, which allows it to connect to the wireless sources, i.e. a smartphone or tablet. When the LED light blinks green once per second, the headphone is ready to connect to the WiFi network.

Once connected, the status LED will remain on and the playback LED will blink once per second.

USB Audio Mode

In USB mode, the function light will remain purple. Charging is disabled when in USB mode.

Battery Level

When charging, the power button LED light will remain red until fully charged, at which point it will turn green.

The power button’s LED light will flash red when power is low. Firmware Update

Firmware Upgrade


HIFIMAN will periodically offer firmware updates to ensure maximum efficiency and performance. It is recommended that you follow the update procedure every 2-3 months.

To update the firmware, clear the network configuration by pressing the WiFi Function button for 3-5 seconds until the light flashes red three times, at which point you should release the button. Once the connection is cleared, the headphone will power down.

Restart the headphone and follow the WiFi network matching procedure detailed in the WiFi Mode LED Display section. When “About” appears on the setup page on your device (see WiFi Connection page), click Manual Update and import the update file. The update will be complete the next time the headphone is turned on.

After the update is complete, restart the headphone and re-match it to the network.

WiFi Connection Mode Operation Instructions



Connecting the HE1000 WiFi to a Network



IMPORTANT: If the headphone is connected to another device in Bluetooth mode by default, it is necessary to enter Forced Pairing mode. To do so, simply insert a pin or paper clip in the Reset Jack. Tap the Function button twice, at which point it will flash red three times. The previously connected device will disengage, allowing you to pair a new source.

Specifications

Frequency Response: 8Hz-65kHz \pm 0.5dB

THD+N: DAC: 0.0055% @-9dB, 1KHz

DAC+AMP: 0.009% @32 Ω , 1KHz

Channel Separation: 105dB @1KHz

Net Weight: 452g

Operating Modes: WiFi, USB Audio, Bluetooth

Battery life under WiFi mode: 6.5-7.5 hours

Battery life under Bluetooth mode: 23 hours

Charging Time: 3-4 hours;

Standby Time: Over 30 days

Audio Formats: PCM 44.1KHz-768KHz, 32/24/16Bit, DSD native 64-512

Bluetooth Codecs: SBC/AAC/aptX/aptX HD/LDAC

Package Contents

(1) Pair of headphones

(1) Pair of ear pads (mounted on headphone)

(1) Owner's Guide

(1) USB cable



HIFIMAN Limited Warranty

Your product is warranted for a period of one year beginning with the original date of purchase. If you join HIFIMAN on Facebook, your product warranty will be extended for an additional six months. Please contact HIFIMAN customer service if you need any assistance.

The dated sales or delivery receipt is your proof of purchase. You may be required to provide proof of purchase as a condition of receiving warranty service so please keep it handy.

If your product is under warranty and malfunctions occur, please contact HIFIMAN customer service or your authorized dealer. If necessary, and at the discretion of HIFIMAN, the company will provide a warranty repair or replacement of your product.

Caution: do not disassemble or modify the product in any way. Tampering with or modifying your HIFIMAN product will void its warranty.

This Limited Warranty does not apply to :

1. Defective or discolored parts if the damages are caused by fluids, dirt, missing keys, broken plastic parts or improper use.
2. Damage caused by misuse with another product.
3. Use of the product for other than its normal intended use, including, without limitation, failure to use the product in accordance with the supplied "Owner's Guide"
4. Damage caused by accident, abuse, neglect or misuse.
5. If you do not have a valid dated receipt showing proof of purchase.
6. Damage caused by services/repairs or other modifications to the system carried out by anyone other than HIFIMAN or an authorized HIFIMAN distributor or dealer.
7. Damage caused by self-repair or if the unit has been disassembled or modified in any way.

HIFIMAN guarantees your satisfaction and will do everything reasonable to achieve that. If you have any questions or concerns with your product, simply contact your authorized dealer or HIFIMAN directly (if purchased from us) and explain the issue in detail. Should a return be required, a RA# will be issued. Return shipping to HIFIMAN or authorized service facility will be at the owner's expense.

The warranty applies to the first purchaser and is not transferable. Should you need warranty service please contact your authorized HIFIMAN dealer. Or email us directly at customerservice@HIFIMAN.com

If you have any concerns with your product: please contact us to explain the issue in detail. If a return/refund is required, a RA# will be issued. Return shipping to HIFIMAN or authorized service facility is done at the owner's expense.

For any further information or questions, please contact your authorized HIFIMAN dealer. Or email us directly at customerservice@HIFIMAN.com.

1. Correct disposing of waste electrical and electronic equipment (WEEE) and symbol of the "crossed-out wheeled bin"

The crossed-out wheeled bin on WEEE means that you are obliged by law to dispose of this equipment separately from the unsorted municipal waste collection system. Disposing of it in the residual waste bin, the yellow bin or yellow bag for recyclable materials is legally prohibited. If the equipment contains portable batteries, accumulators or lamps that are not permanently installed, these must be removed before disposing of the product and be disposed of separately as waste portable batteries.

2. Ways of returning waste electrical and electronic equipment

Owners of waste electrical and electronic equipment can return them to those facilities for returning or collecting waste electrical and electronic equipment set up and provided by the public-sector waste disposal authorities or alternatively with collection points installed by producers, retailers or distant sellers to ensure that the waste electrical and electronic equipment is disposed of correctly. The following link leads to an online registry of the available collection and take-back sites: <https://e-schrott-entsorgen.org/>

3. Data privacy

We should point out to all end-users of waste electrical and electronic equipment that they themselves are responsible for deleting all personal data from the waste electrical and electronic equipment to be disposed of.

WEEE Reg. No. DE 73830605

WEEE Reg. No. DE 48150071



HIFIMAN ELECTRONICS CORPORATION

Address: 2602 Beltagh Ave, Bellmore, NY 11710, USA



facebook.com/hifimanelectronics



twitter.com/hifimanofficial



www.hifiman.com